



Product Evaluation

WIN1295 | 0215

Engineering Services Program

The following product has been evaluated for compliance with the wind loads specified in the International Residential Code (IRC) and the International Building Code (IBC).

This product evaluation is not an endorsement of this product or a recommendation that this product be used. The Texas Department of Insurance has not authorized the use of any information contained in the product evaluation for advertising, or other commercial or promotional purpose.

This product evaluation is intended for use by those individuals who are following the design wind load criteria in Chapter 3 of the IRC and Section 1609 of the IBC. The design loads determined for the building or structure shall not exceed the design load rating specified for the products shown in the limitations section of this product evaluation. This product evaluation does not relieve a Texas licensed engineer of his responsibilities as outlined in the Texas Insurance Code, the Texas Administrative Code, and the Texas Engineering Practice Act.

For more information, contact TDI Engineering Services Program at (800) 248-6032.

Evaluation ID: WIN-1295

Effective Date: February 1, 2015

Re-evaluation Date: January 2018

Product Name: Prime Wood Wide Stile Transom Windows, Non-Impact Resistant

Manufacturer: Lincoln Wood Products, Inc.
1400 West Taylor Street
Merrill, WI 54452
(715) 536-2461

General Description:

System	Description	Label Rating	Design Pressure Rating
1	Prime Wood Wide Stile Transom Windows	TR-C50 111x29	+50 / -50 psf

Product Dimensions:

System	Overall Size	Sash Size
1	110-1/2" x 29"	109" x 27-1/8"

Product Identification (Certification Label on Window):

System		
1	Certification Agency	AAMA
	Manufacturer's Name or Code Name	LN-1
	Product Name	Wood Wide Stile Transom
	Test Standards	AAMA/WDMA/CSA 101/I.S.2/A440-05

Impact Resistance:

System	Impact Resistant	Requirement
1	No	Provide an impact protective system when installing the product in areas that require windborne debris protection.

Installation:

System		
1	Type of Installation	Brickmould
	Wall Framing	Spruce-Pine-Fir Dimension Lumber
	Fasteners	No. 10 x 3" screws
	Fastener Location/Spacing	Approximately 10" from each corner and 10" on center along the perimeter of the window
	Fastener Penetration	Minimum 1-1/2" penetration into the wall framing

Note: Keep the manufacturer's installation instructions available on the job site during installation. Use corrosion resistant fasteners as specified in the IRC, the IBC, and the Texas Revisions.