



TYPICAL ANCHOR PLACEMENT




ANCHOR AT HEAD & SIDE JAMBS

ANCHOR AT INSWING SILL



ANCHOR AT OUTSWING SILL



SEE INSTALLATION SECTION OF THE PRODUCT EVALUATION FOR SPECIFIC ANCHOR DETAILS