

## Goal

Provide information about safety procedures for using hand and power tools.

## Objective

For operators of hand and power tools to learn safe operating techniques.

## Background

Employees can avoid injuries and fatalities by using hand and power and powder-actuated tools properly. This includes using properly adjusted guards on grinders, grinding wheels rated for the grinder's speed, tools equipped with protection from rotating parts, and properly guarded mortar mixers.

The Occupational Safety and Health Administration (OSHA) requires that employers maintain all tools in the workplace in a safe condition, including those furnished by employees. Employers must also perform regular maintenance in accordance with manufacturers' specifications. For best practice, employers should maintain a written preventive maintenance schedule.

Read OSHA's rules for hand and power tool use in general industry in 29 Code of Federal Regulations 1910, Subpart P, Hand and Portable Power Tools and Other Hand-held Equipment. Read the rules for the construction trades in 29 CFR 1926, Subpart I, Tools – Hand and Power. This safety training program provides elements that employers should cover when training employees in the safe use of tools. If any tool becomes defective, train employees to immediately remove it from service and notify their supervisor.

## Using Hand Tools

- Use the right tool for the job. Wrenches are not hammers; knives are not screwdrivers.
- Don't use wrenches when jaws are sprung to the point that slippage occurs.
- Make sure impact tools do not have mushroomed heads.
- Keep tools' wooden handles free of splinters and cracks, and don't use tools with loose handles.

## Using Power Tools

### Electric Tools

- Only use electric tools that are double-insulated or grounded with a grounding prong. Do not use the tool if prong is missing.
- Never use electric cords for hoisting or lowering tools.
- Replace cords that have damaged insulation. Don't tape over the damage.

### Pneumatic Tools

- Secure all pneumatic tools to the air supply hose or whip to prevent disconnecting.
- Never carry tools by the hose.
- Use clips or retainers to secure all attachments used on pneumatic tools.
- Provide a muzzle safety on pneumatic nailers or staplers when they operate at or above 100 pounds per square inch (psi) to prevent the tool from activating when they are not in contact with the work surface.
- Never use compressed air above 30 psi for cleaning purposes – and then, only with effective chip guarding and personal protective equipment (PPE).

### Fuel-Powered Tools

- Follow proper fueling procedures, including equipment shutdown, when using fuel-powered tools.
- Use adequate ventilation and PPE to protect employees from the toxic fumes that this type of equipment emits.

### Hydraulic Tools

- Use only fire-resistant fluids in hydraulic tools.
- Follow all manufacturer's operating procedures.

### Powder-actuated (or Explosive-actuated) Fastening Tools

- Train all operators how to use these tools.
- Conduct daily tests to verify that all safety devices are working.

- Ensure that operators always use the correct shield or guard for the tool, and that they wear the proper PPE.
- Never put fasteners into hard or brittle material that could chip or splinter – doing so could cause the fastener to ricochet. Such materials include cast iron, glazed tile, surface-hardened steel, glass block, live rock, face brick, and hollow tile. Use a backing to avoid over-penetration when working with soft materials.
- Never load tools until just before they are used.
- Never point a powder-actuated fastening tool at someone.
- Never leave a loaded tool unattended.
- Never use powder-actuated tools in an explosive or flammable environment.

### Abrasive Wheel Tools

- Make sure proper guards are in place and correctly adjusted. Adjust tool work rests so that the maximum clearance between the rest and the wheel does not exceed 1/8 inch.
- Wear the correct eye protection for the job.
- Make sure the wheel is rated for the speed of the motor.
- Inspect wheels for defects using the ring test – hold the wheel with one finger through the center hole and strike it with a wooden or hard plastic screwdriver handle at a point 45 degrees from the vertical centerline and 1 to 2 inches from the outer rim. A wheel in good condition will give a clear, metallic ring; a damaged wheel will not.

### Switches

The following hand-held tools may be equipped with only a positive on-off switch:

- platen sanders;
- disc sanders;
- grinders with wheels 2 inches or less in diameter;
- routers;
- planers;
- laminate trimmers;
- shears; and
- scroll, saber, or jig saws with blade shanks 1/4 inch wide or less.

All other tools must be equipped with a spring-loaded switch that turns off when the operator releases finger pressure.

## Using Bench and Floor-Mounted Power Tools

### Guarding

- Guard all exposed belts, chains, gears, drums, flywheels, or other reciprocating or moving parts.
- Make sure barrier guards, proximity sensors, or two-handed tripping devices are in place before using any machine.
- Provide guards to protect employees from flying chips, sparks, abrasives, or splashes.
- Guard ventilation fans unless they are at least 7 feet above the floor. Make sure fan guards have maximum openings no larger than 1/2 inch.
- Guard the point of operation, where work is actually performed or material is processed, if it exposes an employee to injury. Examples of machines requiring this type of guarding include shears, alligator cutters, power presses, milling machines, forming rollers, and calenders.
- Securely anchor all machines in a fixed location to prevent their walking or moving upon contact.

### Woodworking Tools

#### Disconnect Switches

Ensure that all woodworking tools have a disconnect switch that can be locked or tagged out in the OFF position.

#### Speeds

All circular saws more than 20 inches in diameter, or operating at more than 10,000 peripheral feet per minute, must be etched or permanently marked with the correct operating speed.

#### Guarding

- Guard all circular saws above and below the base plate and the shoe. Immediately return guards to the covering position at the end of the cut.
- Completely enclose by a hood the upper portion of a radial saw's blade, including the saw arbor.
- Guard the full diameter of the lower exposed portion of the blade.
- Ensure that the guarding device will automatically adjust itself to the thickness of the stock and remain in contact with the stock during the cut.
- Completely enclose by a hood the portion of a circular, hand-fed rip saw above the material being cut.

## Review Questions

1. What requirement applies to all tools?
  - a. Keep tools covered at all times.
  - b. Keep tools in a safe condition.
  - c. Do not use any tool without a permit.
  - d. Keep tools outside.
2. What is the maximum distance allowed between a tool rest and abrasive wheels?
  - a. 1/8 inch
  - b. 1/4 inch
  - c. 1/2 inch
  - d. 1 inch
3. What is the maximum psi allowed when using compressed air for cleaning purposes?
  - a. 10 pounds psi
  - b. 20 pounds psi
  - c. 30 pounds psi
  - d. 40 pounds psi
4. Which of the following is not a rule for using powder-actuated fastening tools?
  - a. Never load tools until just before they are used.
  - b. Never leave a loaded tool unattended.
  - c. Use only fire-resistant fluids.
  - d. Never use tools in an explosive or flammable environment.
5. Which of the following techniques apply when using hand tools?
  - a. Make sure impact tools do not have mushroomed heads.
  - b. Don't use tools with loose handles, and keep tools' wooden handles free of splinters and cracks.
  - c. Always use the right tool for the job.
  - d. All of the above.
6. When using fuel-powered tools, an important rule is to be sure to use adequate ventilation and PPE to protect against the toxic fumes that this type of equipment emits.
  - a. True
  - b. False
7. The test for inspecting the wheels of abrasive tools for defects is known as:
  - a. The knock test
  - b. The tap test
  - c. The tone test
  - d. The ring test
8. Fan guards for bench and floor-mounted power tools must be no larger than:
  - a. 1/8 inch
  - b. 1/4 inch
  - c. 1/2 inch
  - d. 1 inch
9. What must be etched or permanently marked on all circular saws more than 20 inches in diameter or operating at more than 10,000 peripheral feet per minute?
  - a. The correct operating speed
  - b. The date of manufacture
  - c. The brand name
  - d. The country of origin
10. Which of these hand-held tools may be equipped with only a positive on-off switch?
  - a. Platen and disc sanders
  - b. Planers
  - c. Laminate trimmers
  - d. All of the above

## Answers

1. **b.** Keep tools in a safe condition. If any tool becomes defective, immediately remove it from service and notify a supervisor.
2. **a.** 1/8 inch
3. **c.** 30 pounds psi
4. **c.** Use only fire-resistant fluids
5. **d.** All of the above
6. **a.** True
7. **d.** The ring test. A wheel in good condition will give a clear, metallic ring; a damaged wheel will not.
8. **c.** 1/2 inch
9. **a.** The correct operating speed
10. **d.** All of the above. All other tools must be equipped with a spring-loaded switch that turns off when the operator releases finger pressure.

Unless otherwise noted, this document was produced by the Division of Workers' Compensation (DWC) using information from staff subject specialists, governmental entities, or other authoritative sources. It is considered accurate at the time of publication.

For more free DWC safety and health publications, visit [www.tdi.texas.gov/wc/safety/videoresources/index.html](http://www.tdi.texas.gov/wc/safety/videoresources/index.html).

DWC features a free occupational safety and health audiovisual loan library. Call (800) 252-7031, option 2, for more information or visit the TDI website at [www.tdi.texas.gov/wc/safety/videoresources/avcatalog.html](http://www.tdi.texas.gov/wc/safety/videoresources/avcatalog.html).

DWC Workplace Safety: (800) 252-7031, option 2, or [resourcecenter@tdi.texas.gov](mailto:resourcecenter@tdi.texas.gov).