

Impact Resistance:

System	Impact Resistant	Requirement
1	No	Provide an impact protective system when installing the product in areas that require windborne debris protection.

Installation:**System 1 (Use One of the Following):**

Option 1: Use minimum Southern Yellow Pine dimension lumber. The window is secured to the wall framing using galvanized steel installation clips (1-5/8" x 10-1/16" x 0.04"). The installation clips are spaced 18" from each corner and 18" on center along the side jambs and 16" from each corner along the head and the sill. Each clip is attached to the window with two, No. 8 x 3/4" screws and to the wall framing with one, No. 8 x 1-3/4" screw. The fasteners must be long enough to penetrate a minimum of 1-1/2" into the wall framing.

Option 2: Use minimum Southern Yellow Pine dimension lumber. The window is secured to the wall framing using minimum No. 10 x 2-1/2" screws. The fasteners are spaced 18" from each corner and 18" on center along the side jambs and 12" from each corner along the head and the sill. The fasteners must be long enough to penetrate a minimum of 1-1/2" into the wall framing.

Note: Keep the manufacturer's installation instructions available on the job site during installation. Use corrosion resistant fasteners as specified in the IRC, the IBC, and the Texas Revisions.