




NAIL FIN INSTALLATION



Max Frame	DP RATING	IMPACT
96" x 60"	+50/-55	NO

### Installation Notes:

- Seal flange/frame to substrate. Sill shall be set on a continuous serpentine bead of structural grade silicone caulk when no fastener is used to anchor the sill (typical).
- Use #8 PH or greater fastener though the nail fin with sufficient length to penetrate a minimum of 1 1/2" into the wood framing. For 2X wood frame substrate (min. S.G. = 0.42).
- Host structure (wood buck, masonry, steel) to be designed and anchored to properly transfer all loads to the structure. The host structure is the responsibility of the architect or engineer of record for the project of installation.


#### General Notes:

- The product shown herein is designed, tested and manufactured to comply with the wind load criteria of the 2018 International Residential Code(IRC), the 2018 International Building Code(IBC).
- All glazing shall conform to ASTM E1300.
- At minimum, fixed Lite glazing shall be 4.7mm annealed 13.0mm airspace 4.7mm annealed. At minimum Sash Lites glazing shall be 3.0mm annealed - 13.0mm airspace - 3.0mm annealed.
- Use structural or composite shims where required.


This schedule addresses only the fasteners required to anchor the window to achieve the rated design pressure up to the size limitations noted. It is not intended as a guide to the installation process and does not address the sealing consideration that may arise in different wall conditions. For the complete installation procedure, see the instructions packaged with the window or go to www.jeld-wen.com.


## DISCLAIMER:

This drawing and its contents are confidential and are not to be reproduced or copied in whole or in part or used or disclosed to others except as authorized by JELD-WEN Inc.










## THROUGH FRAME INSTALLATION



Max Frame	DP RATING	IMPACT
96" x 60"	+50/-55	NO

## Installation Notes:

- 1. Seal flange/frame to substrate. Sill shall be set on a continuous serpentine bead of structural grade silicone caulk when no fastener is used to anchor the sill (typical).
- 2. Use #8 PH or greater fastener through the jambs with sufficient length to penetrate a minimum of 1 1/2" into the wood framing. For two (2X) wood frame substrate (min. S.G. = 0.42).
- Host structure (wood buck, masonry, steel) to be designed and anchored to properly transfer all loads to the structure. The host structure is the responsibility of the architect or engineer of record for the project of installation.


# This schedule addresses only the fasteners required to anchor the window to achieve the rated design pressure up to the size limitations noted. It is not intended as a guide to the installation process and does not address the sealing consideration that may arise in different wall conditions. For the complete installation procedure, see the instructions packaged with the window or go to www.ield-wen.com.

### DISCLAIMER:


This drawing and its contents are confidential and are not to be reproduced or copied in whole or in part or used or disclosed to others except as authorized by JELD-WEN Inc.




- The product shown herein is designed, tested and manufactured to comply with the wind load criteria
  of the 2018 International Residential Code(IRC), the 2018 International Building Code(IBC).
- All glazing shall conform to ASTM E1300.
- At minimum, fixed Lite glazing shall be 4.7mm annealed 13.0mm airspace 4.7mm annealed. At minimum Sash Lites glazing shall be 3.0mm annealed - 13.0mm airspace - 3.0mm annealed.
- Use structural or composite shims where required.




		DATE: 03/31/2021	TET		T			akeport	
	DRAWN BY: J.HAWKINS	SCALE: NTS	JELB WEN		4			s, OR 9: 0) 535-:	
	CHECKED BY: D.BELAU	TITLE:							
	APPROVED BY: J.GOOSSEN	Premium Vinyl Horizontal Slider XOX Window							
	D011888								
3	REPORT No: SJW2014-132 / S	5JW2014-133		CAD DWG. No.: PremVinvIHSXOX Cert	REV:	Α	SHEET	2 OF 4	





## MASONRY INSTALLATION



Max Frame	DP RATING	IMPACT
96" x 60"	+50/-55	70

## Installation Notes:

- Seal flange/frame to substrate. Sill shall be set on a continuous serpentine bead of structural grade silicone caulk when no fastener is used to anchor the sill (typical).
- 2. Use 3/16" Tapcon or equivalent fastener through frame with sufficient length to penetrate a minimum of 1 1/2" into concrete (min. f'c = 3000 psi) or masonry (per ASTM C-90).
- Host structure (wood buck, masonry, steel) to be designed and anchored to properly transfer all loads to the structure. The host structure is the responsibility of the architect or engineer of record for the project of installation.


# This schedule addresses only the fasteners required to anchor the window to achieve the rated design pressure up to the size limitations noted. It is not intended as a guide to the installation process and does not address the sealing consideration that may arise in different wall conditions. For the complete installation procedure, see the instructions packaged with the window or go to www.jeld-wen.com.


## DISCLAIMER:


This drawing and its contents are confidential and are not to be reproduced or copied in whole or in part or used or disclosed to others except as authorized by JELD-WEN Inc.





- The product shown herein is designed, tested and manufactured to comply with the wind load criteria
  of the 2018 International Residential Code(IRC), the 2018 International Building Code(IBC).
- 2. All glazing shall conform to ASTM E1300.
- 3. At minimum, fixed Lite glazing shall be 4.7mm annealed 13.0mm airspace 4.7mm annealed. At minimum Sash Lites glazing shall be 3.0mm annealed 13.0mm airspace 3.0mm annealed.
- Use structural or composite shims where required.











STEEL INSTALLATION

Max Frame	DP RATING	IMPACT
96" x 60"	+50/-55	70

## Installation Notes:

- Seal flange/frame to substrate. Sill shall be set on a continuous serpentine bead of structural grade silicone caulk when no fastener is used to anchor the sill (typical).
- For anchoring into metal framing, use #8 TEK Self Tapping screws with sufficient length to achieve a minimum penetration of three threads past the frame thickness. Locate anchors as shown in elevations and installation details.
- Host structure (wood buck, masonry, steel) to be designed and anchored to properly transfer all loads
  to the structure. The host structure is the responsibility of the architect or engineer of record for the
  project of installation.

This schedule addresses only the fasteners required to anchor the window to achieve the rated design pressure up to the size limitations noted. It is not intended as a guide to the installation process and does not address the sealing consideration that may arise in different wall conditions. For the complete installation procedure, see the instructions packaged with the window or go to www.jeld-wen.com.

## DISCLAIMER:

This drawing and its contents are confidential and are not to be reproduced or copied in whole or in part or used or disclosed to others except as authorized by JELD-WEN Inc.



- The product shown herein is designed, tested and manufactured to comply with the wind load criteria
  of the 2018 International Residential Code(IRC), the 2018 International Building Code(IBC).
- 2. All glazing shall conform to ASTM E1300.
- 3. At minimum, fixed Lite glazing shall be 4.7mm annealed 13.0mm airspace 4.7mm annealed. At minimum Sash Lites glazing shall be 3.0mm annealed 13.0mm airspace 3.0mm annealed.
- Use structural or composite shims where required.

