

Anchor: ITW Tapcon or Tapcon LDT or Simpson Strong-Tie.

ITW Ramset/ Redhead Tapcon, 1/4" diameter, minimum 3.5" long with washer that conforms to ANSI B18.22.1 type B.

ITW Ramset/ Redhead Large Diameter Tapcon, 3/8" diameter, minimum 4" long with washer that conforms to ANSI B18.22.1 type B.

Simpson Titen HD, 3/8" diameter, minimum 4" long with washer that conforms to ANSI B18.22.1 type B.

Simpson Wedge-All, 3/8" diameter, minimum 4" long with washer that conforms to ANSI B18.22.1 type B.


When applying back jams over dry wall or other non structural wall covering, use longer fasteners to insure minimum embedment required.

This chart applies to wood species with specific gravity greater than or equal to 0.42 including spruce pine fir (SPF) and southern pine (SP).

See chart for minimum washer diameter. Washer diameters in chart are based on use of Spruce Pine Fir. Washers may be 10% smaller when Southern Pine is used.

See chart for minimum edge distance required. Lowest anchor to be greater than the minimum edge distance up from the floor and less than 10-inches from the floor.

keep each area clear of any back jamb attachment fasteners



**FASTENER SPACING (inches)**

**2500 psi concrete**      **Filled CMU**

**ITW Tapcon**      **Simpson Strong-Tie**

**DOOR WIDTH (feet and inches) at a given DESIGN PRESSURE (PSF)**

1/4"	1/4"	3/8"	3/8"	3/8"	3/8"	14psf	17psf	20psf	24psf	28psf	32psf	36psf	40psf	44psf	48psf	53psf	58psf	63psf	69psf	75psf	81psf	87psf	93psf
24	24	24	24	24	24	22'-9	18'-9	15'-11	13'-3	11'-4	9'-11	8'-10	7'-11	7'-3	6'-7	6'-0	5'-6	5'-0	4'-7	4'-3	3'-11	n/a	n/a
24	22	24	24	24	24	24'-3	20'-0	17'-0	14'-1	12'-1	10'-7	9'-5	8'-6	7'-8	7'-0	6'-4	5'-10	5'-4	4'-11	4'-6	4'-2	n/a	n/a
24	20	24	24	24	16	26'-6	21'-9	18'-6	15'-5	13'-3	11'-7	10'-3	9'-3	8'-5	7'-8	7'-0	6'-4	5'-10	5'-4	4'-11	4'-6	4'-3	3'-11
24	18	24	22	24	16	28'-10	23'-9	20'-2	16'-10	14'-5	12'-7	11'-2	10'-1	9'-2	8'-5	7'-7	6'-11	6'-5	5'-10	5'-4	4'-11	4'-7	4'-4
24	17	24	20	24	16	31'-9	26'-2	22'-3	18'-6	15'-10	13'-10	12'-4	11'-1	10'-1	9'-3	8'-4	7'-8	7'-0	6'-5	5'-11	5'-5	5'-1	4'-9
24	15	24	18	24	16	34'-3	28'-2	24'-0	20'-0	17'-1	15'-0	13'-4	12'-0	10'-10	10'-0	9'-0	8'-3	7'-7	6'-11	6'-4	5'-11	5'-6	5'-1
24	15	24	17	16	16	36'-3	29'-10	25'-4	21'-2	18'-1	15'-10	14'-1	12'-8	11'-6	10'-7	9'-7	8'-9	8'-0	7'-4	6'-9	6'-3	5'-10	5'-5
22	13	24	16	16	8	n/a	32'-3	27'-5	22'-10	19'-7	17'-1	15'-2	13'-8	12'-5	11'-5	10'-4	9'-5	8'-8	7'-11	7'-3	6'-9	6'-3	5'-10
21	13	24	15	16	8	n/a	33'-10	28'-9	24'-0	20'-6	18'-0	16'-0	14'-4	13'-1	12'-0	10'-10	9'-11	9'-1	8'-4	7'-8	7'-1	6'-7	6'-2
19	12	24	14	16	8	n/a	n/a	31'-4	26'-1	22'-5	19'-7	17'-5	15'-8	14'-3	13'-0	11'-10	10'-9	9'-11	9'-1	8'-4	7'-8	7'-2	6'-8
16	10	24	12	16	8	n/a	n/a	36'-0	30'-0	25'-8	22'-6	20'-0	18'-0	16'-4	15'-0	13'-7	12'-4	11'-5	10'-5	9'-7	8'-10	8'-3	7'-8
16	10	24	11	8	8	n/a	n/a	n/a	31'-9	27'-2	23'-9	21'-2	19'-0	17'-3	15'-10	14'-4	13'-1	12'-1	11'-0	10'-1	9'-4	8'-9	8'-2
14	8	24	10	8	8	n/a	n/a	n/a	35'-9	30'-8	26'-10	23'-10	21'-5	19'-6	17'-10	16'-2	14'-9	13'-7	12'-5	11'-5	10'-7	9'-10	9'-2
12	7	20	9	8	8	n/a	n/a	n/a	n/a	n/a	30'-11	27'-5	24'-8	22'-5	20'-7	18'-8	17'-0	15'-8	14'-4	13'-2	12'-2	11'-4	10'-7
11	7	20	8	8	8	n/a	n/a	n/a	n/a	n/a	31'-10	28'-3	25'-6	23'-2	21'-3	19'-2	17'-7	16'-2	14'-9	13'-7	12'-7	11'-8	10'-11
10	6	17	7	8	n/a	n/a	n/a	n/a	n/a	n/a	n/a	32'-0	28'-9	26'-2	24'-0	21'-8	19'-10	18'-3	16'-8	15'-4	14'-2	13'-2	12'-4
9	n/a	16	6	8	n/a	n/a	n/a	n/a	n/a	n/a	n/a	n/a	32'-0	29'-1	26'-8	24'-1	22'-0	20'-3	18'-6	17'-0	15'-9	14'-8	13'-9
8	n/a	13	6	n/a	n/a	n/a	n/a	n/a	n/a	n/a	n/a	n/a	n/a	n/a	30'-11	28'-0	25'-7	23'-6	21'-6	19'-9	18'-3	17'-0	15'-11
n/a	n/a	12	n/a	n/a	n/a	n/a	n/a	n/a	n/a	n/a	n/a	n/a	n/a	n/a	32'-4	29'-7	27'-3	24'-10	22'-10	21'-2	19'-8	18'-5	17'-5


**2500 psi concrete**      **Filled CMU**

**ITW Tapcon**      **ITW LDT**      **Titen HD**      **Wedge-All**

**DOOR WIDTH (feet and inches) at a given DESIGN PRESSURE (PSF)**

1/4"	1/4"	3/8"	3/8"	3/8"	3/8"
1.75"	1.75"	2.5"	2.5"	2.75"	2.68"
1-1/8"	7/8"	1-1/2"	1"	1-1/8"	1-1/8"
2-1/2"	2-1/2"	3"	3"	4"	4"
508#	319#	859#	371#	480#	340#

FASTENER DIAMETER  
 EMBEDMENT LENGTH  
 WASHER DIAMETER  
 EDGE DISTANCE  
 FASTENER LOAD CAPACITY



Supporting structural elements shall be designed by a registered professional engineer for wind loads in addition to other loads. This drawing does not address the jamb/wall design, but only door attachment. Jamb/wall construction is shown only for illustration purposes. The building designer is responsible for ensuring that the jamb/wall is sufficient to carry the door live and static loads. This drawing does not address the spring pad connections. Registered professional engineer may approved an alternative design.

Manufacturer's installation instructions must be followed.

Maximum spacing shown in chart.

Lesser spacing may be used to avoid interference with door hardware and or fastening system, but not less than 6".

Load per jamb = 0.5 x door width x max positive pressure x door height.

8" CMU block walls shall comply with ASTM C90.

Use minimum 2000 psi grout or concrete when filling CMU.

CMU fastener spacing distance may vary +/-1".

John E. Scates, P.E.  
 3121 Fairgate Drive  
 Carrollton, Texas 75007  
 Florida P.E. # 51737  
 TXPE 56308, F-2203

Professional Engineer's seal provided only for verification of windload construction details.

	SCALE	none
	DATE	2-18-2015
<b>Back Jamb Attachment Detail</b> <b>Concrete Anchors</b>		
<b>C.H.I. Drawing: BJA-101</b>		<b>Rev.-07</b>

Use SP values only if both structure and jamb are Southern Pine.  
 Use SPF values when Spruce-Pine-Fir is present in structure or jamb material.  
 Lesser spacing may be used to avoid interference with door hardware and or fastening system.  
 Maximum spacing shown in chart.  
 Lag screw: 3/8" diameter x 3" minimum long; must conform to ANSI/ASME B18.2.1  
 When applying back jamba over dry wall or other non structural wall covering,  
 use longer lags screws to insure 1-1/2" minimum embedment required.  
 Washer: 1-1/8" minimum outside diameter, must conform to ANSI B18.22.1 type A.  
 Pre-drill 1/4" diameter pilot holes for lag screw insertion. 1-1/2" minimum lag screw edge distance required.

**Spruce-Pine-Fir (SPF)**



**MAX LAG SCREW SPACING (Inches) FOR DOOR WIDTH (max) vs DESIGN PRESSURE**

MAX WIDTH IN FEET	DESIGN PRESSURE IN POUNDS-PER-SQUARE-FOOT (PSF)													
	12 PSF	15 PSF	18 PSF	21 PSF	24 PSF	27 PSF	30 PSF	33 PSF	36 PSF	39 PSF	42 PSF	46 PSF	50 PSF	53 PSF
≤ 9'	24"	24"	24"	24"	24"	24"	24"	24"	24"	24"	24"	24"	24"	24"
10'	24"	24"	24"	24"	24"	24"	24"	24"	24"	24"	24"	24"	23"	21"
12'	24"	24"	24"	24"	24"	24"	24"	24"	24"	24"	22"	20"	19"	18"
14'	24"	24"	24"	24"	24"	24"	24"	24"	22"	21"	19"	17"	16"	15"
15'	24"	24"	24"	24"	24"	24"	24"	23"	21"	19"	18"	16"	15"	14"
16'	24"	24"	24"	24"	24"	24"	24"	21"	20"	18"	17"	15"	14"	13"
18'	24"	24"	24"	24"	24"	23"	21"	19"	17"	16"	15"	13"	12"	12"
20'	24"	24"	24"	24"	24"	21"	19"	17"	16"	14"	13"	12"	11"	10"
22'	24"	24"	24"	24"	21"	19"	17"	15"	14"	13"	12"	11"	10"	9"
24'	24"	24"	24"	22"	20"	17"	16"	14"	13"	12"	11"	10"	9"	9"
26'	24"	24"	24"	21"	18"	16"	14"	13"	12"	11"	10"	9"	8"	8"
30'	24"	24"	21"	18"	16"	14"	12"	11"	10"	9"	9"	8"	7"	7"

**Southern Pine (SP)**

**MAX LAG SCREW SPACING (Inches) FOR DOOR WIDTH (max) vs DESIGN PRESSURE**

MAX WIDTH IN FEET	DESIGN PRESSURE IN POUNDS-PER-SQUARE-FOOT (PSF)													
	12 PSF	15 PSF	18 PSF	21 PSF	24 PSF	27 PSF	30 PSF	33 PSF	36 PSF	39 PSF	42 PSF	46 PSF	50 PSF	53 PSF
≤ 10'	24"	24"	24"	24"	24"	24"	24"	24"	24"	24"	24"	24"	24"	24"
12'	24"	24"	24"	24"	24"	24"	24"	24"	24"	24"	24"	24"	24"	23"
14'	24"	24"	24"	24"	24"	24"	24"	24"	24"	24"	24"	23"	21"	20"
15'	24"	24"	24"	24"	24"	24"	24"	24"	24"	24"	23"	21"	19"	18"
16'	24"	24"	24"	24"	24"	24"	24"	24"	24"	23"	22"	20"	18"	17"
18'	24"	24"	24"	24"	24"	24"	24"	24"	22"	21"	19"	17"	16"	15"
20'	24"	24"	24"	24"	24"	24"	24"	22"	20"	19"	17"	16"	14"	14"
22'	24"	24"	24"	24"	24"	24"	22"	20"	18"	17"	16"	14"	13"	12"
24'	24"	24"	24"	24"	24"	22"	20"	18"	17"	15"	14"	13"	12"	11"
26'	24"	24"	24"	24"	23"	21"	19"	17"	15"	14"	13"	12"	11"	10"
30'	24"	24"	24"	23"	20"	18"	16"	15"	13"	12"	11"	10"	9"	9"



Southern Pine (SP) specific gravity = 0.55; load per anchor = 620 pounds.  
 Spruce-Pine-Fir (SPF) specific gravity = 0.42; load per anchor = 482 pounds.  
 Maximum load per jamb = 0.5 x (door height) x (door width) x (maximum positive pressure)  
 These charts do not address spring pad connections to the building.  
 Alternative design may be approved by a registered professional engineer.  
 Supporting structural elements shall be designed by a registered professional engineer for wind loads in addition to other loads.

Professional Engineer's seal provided only for verification of windload construction details.

John E. Scates, P.E.  
 3121 Fairgate Drive  
 Carrollton, Texas 75007  
 Florida P.E. # 51737  
 TXPE 56308, F-2203

	SCALE	none
	DATE	4-25-2017
<b>Back Jamb Attachment Detail</b> <b>Lag Screw</b>		
C.H.I. Drawing: BJA-102		Rev.-06



Simpson Titen HD; 3/8" diameter x 3" long (minimum).

Simpson Wedge-All; 3/8" diameter x 3" long (minimum).

ITW Ramset/ Redhead Large Diameter Tapcon, 3/8" diameter, minimum 2" long with washer that conforms to ANSI B18.22.1 type B.

Use a fastener for every track bracket unless the quantity of fasteners determined from this chart is more than the quantity of track brackets specified on the door drawing.

Add track brackets as required to satisfy fastener spacing in these charts. Maximum spacing shown in chart.

Lesser spacing may be used to avoid interference with door hardware and or fastening system, but not less than 6".


See chart for minimum edge distance required.

Load per jamb = 0.5 x door width x max positive pressure x door height

Manufacturer's installation instructions must be followed.

8" CMU block walls shall comply with ASTM C90. Use minimum 2000 psi grout or concrete when filling CMU.

Fastener spacing distance may vary +/-1".



**FASTENER  
SPACING  
(inches)**

**Filled CMU DOOR WIDTH (feet and inches) at a given DESIGN PRESSURE (PSF)**

Simpson Titen HD	Simpson Wedge-All	14psf	17psf	20psf	24psf	28psf	32psf	36psf	40psf	44psf	48psf	53psf	58psf	63psf	69psf	75psf	81psf	87psf	93psf
n/a	24	24'-3	20'-0	17'-0	14'-2	12'-1	10'-7	9'-5	8'-6	7'-8	7'-1	6'-4	5'-10	5'-4	4'-11	4'-6	4'-2	n/a	n/a
24	16	34'-3	28'-2	24'-0	20'-0	17'-1	15'-0	13'-4	12'-0	10'-10	10'-0	9'-0	8'-3	7'-7	6'-11	6'-4	5'-11	5'-6	5'-1
16	16	36'-5	30'-0	25'-6	21'-3	18'-2	15'-11	14'-2	12'-9	11'-7	10'-7	9'-7	8'-9	8'-1	7'-4	6'-9	6'-3	5'-10	5'-5
16	8	n/a	n/a	36'-0	30'-0	25'-8	22'-6	20'-0	18'-0	16'-4	15'-0	13'-7	12'-4	11'-5	10'-5	9'-7	8'-10	8'-3	7'-8
8	8	n/a	n/a	n/a	n/a	n/a	31'-10	28'-4	25'-6	23'-2	21'-3	19'-2	17'-7	16'-2	14'-9	13'-7	12'-7	11'-8	10'-11
8	n/a	n/a	n/a	n/a	n/a	n/a	n/a	n/a	n/a	32'-8	30'-0	27'-2	24'-9	22'-10	20'-10	19'-2	17'-9	16'-6	15'-5

Simpson Titen HD	Simpson Wedge-All	14psf	17psf	20psf	24psf	28psf	32psf	36psf	40psf	44psf	48psf	53psf	58psf	63psf	69psf	75psf	81psf	87psf	93psf
------------------	-------------------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------	-------

**DOOR WIDTH (feet and inches) at a given DESIGN PRESSURE (PSF)**

**3/8" FASTENER DIAMETER**

**2.75" EMBEDMENT LENGTH**

**4" EDGE DISTANCE**

**480# FASTENER LOAD CAPACITY**

These charts do not address spring pad connections to building.

Alternative design may be approved by a registered professional engineer.

Supporting structural elements shall be designed by a registered professional engineer for wind loads in addition to other loads.


This drawing does not address the wall design, but only door attachment. Wall construction is shown only for illustration purposes. The building designer is responsible for ensuring that the wall is sufficient to carry the door live and static loads.

John E. Scates, P.E.  
3121 Fairgate Drive  
Carrollton, Texas 75007  
Florida P.E. # 51737  
TXPE 56308, F-2203

Professional Engineer's seal provided only for verification of windload construction details.

	SCALE	none
	DATE	2-18-2015
<b>CMU Block Wall Attachment Detail</b>		
C.H.I. Drawing: BJA-104		Rev.-07

Anchor: ITW Tapcon or Tapcon LDT or Simpson Strong-Tie Wedge-All.  
 ITW Ramset/ Redhead Tapcon, 1/4" diameter, 2" long (minimum)  
 ITW Ramset/ Redhead Large Diameter Tapcon, 3/8" diameter, 2-3/4" long (minimum)  
 Simpson Wedge-All; 3/8" diameter x 2" long (minimum).  
 Use a fastener for every track bracket unless the quantity of fasteners determined from this chart is more than the quantity of track brackets specified on the door drawing.  
 Add track brackets as required to satisfy fastener spacing in these charts. Maximum spacing shown in chart. Lesser spacing may be used to avoid interference with door hardware and or fastening system, but not less than 6". See chart for minimum edge distance required.  
 Concrete walls shall be minimum 2500 psi concrete and shall be of sufficient strength to resist loads.  
 Load per jamb = 0.5 x door width x max positive pressure x door height.  
 Manufacturer's installation instructions must be followed.



FASTENER SPACING 2500 psi concrete		
ITW Tapcon		Simpson Strong-Tie 3/8" Wedge-All
1/4"	3/8"	3/8"
1.75"	2.5"	2.68"
2.5"	3"	4"
508#	764#	340#

DOOR WIDTH (feet and inches) at a given DESIGN PRESSURE (PSF)																					
14psf	17psf	20psf	24psf	28psf	32psf	36psf	40psf	44psf	48psf	53psf	58psf	63psf	69psf	75psf	81psf	87psf	93psf				
24'-3"	20'-0"	17'-0"	14'-2"	12'-1"	10'-7"	9'-5"	8'-6"	7'-8"	7'-1"	6'-4"	5'-10"	5'-4"	4'-11"	4'-6"	4'-2"	n/a	n/a				
26'-5"	21'-9"	18'-6"	15'-5"	13'-2"	11'-7"	10'-3"	9'-3"	8'-5"	7'-8"	6'-11"	6'-4"	5'-10"	5'-4"	4'-11"	4'-6"	4'-3"	3'-11"				
29'-1"	24'-0"	20'-4"	17'-0"	14'-6"	12'-9"	11'-4"	10'-2"	9'-3"	8'-6"	7'-8"	7'-0"	6'-5"	5'-10"	5'-5"	5'-0"	4'-8"	4'-4"				
32'-4"	26'-8"	22'-8"	18'-10"	16'-2"	14'-2"	12'-7"	11'-4"	10'-3"	9'-5"	8'-6"	7'-9"	7'-2"	6'-6"	6'-0"	5'-7"	5'-2"	4'-10"				
36'-3"	29'-10"	25'-4"	21'-2"	18'-1"	15'-10"	14'-1"	12'-8"	11'-6"	10'-7"	9'-7"	8'-9"	8'-0"	7'-4"	6'-9"	6'-3"	5'-10"	5'-5"				
n/a	31'-8"	26'-11"	22'-5"	19'-3"	16'-10"	14'-11"	13'-5"	12'-3"	11'-2"	10'-2"	9'-3"	8'-6"	7'-9"	7'-2"	6'-7"	6'-2"	5'-9"				
n/a	33'-8"	28'-7"	23'-10"	20'-5"	17'-10"	15'-11"	14'-3"	13'-0"	11'-11"	10'-9"	9'-10"	9'-1"	8'-3"	7'-7"	7'-0"	6'-7"	6'-1"				
n/a	35'-11"	30'-6"	25'-5"	21'-9"	19'-1"	16'-11"	15'-3"	13'-10"	12'-8"	11'-6"	10'-6"	9'-8"	8'-10"	8'-1"	7'-6"	7'-0"	6'-6"				
n/a	n/a	35'-3"	29'-4"	25'-2"	22'-0"	19'-7"	17'-7"	16'-0"	14'-8"	13'-3"	12'-1"	11'-2"	10'-2"	9'-4"	8'-8"	8'-1"	7'-6"				
n/a	n/a	n/a	31'-9"	27'-3"	23'-10"	21'-2"	19'-1"	17'-4"	15'-11"	14'-4"	13'-2"	12'-1"	11'-0"	10'-2"	9'-5"	8'-9"	8'-2"				
n/a	n/a	n/a	n/a	32'-8"	28'-7"	25'-5"	22'-11"	20'-10"	19'-1"	17'-3"	15'-9"	14'-6"	13'-3"	12'-2"	11'-3"	10'-6"	9'-10"				
n/a	n/a	n/a	n/a	n/a	31'-9"	28'-7"	26'-0"	23'-10"	21'-7"	19'-9"	18'-2"	16'-7"	15'-3"	14'-1"	13'-2"	12'-3"	12'-3"				
n/a	n/a	n/a	n/a	n/a	n/a	32'-8"	29'-9"	27'-3"	24'-8"	22'-6"	20'-9"	18'-11"	17'-5"	16'-2"	15'-0"	14'-0"	14'-0"				
n/a	n/a	n/a	n/a	n/a	n/a	n/a	n/a	n/a	31'-9"	28'-9"	26'-3"	24'-2"	22'-1"	20'-3"	18'-9"	17'-6"	16'-4"				


ITW Tapcon		Simpson Strong-Tie	14psf	17psf	20psf	24psf	28psf	32psf	36psf	40psf	44psf	48psf	53psf	58psf	63psf	69psf	75psf	81psf	87psf	93psf	
DOOR WIDTH (feet and inches) at a given DESIGN PRESSURE (PSF)																					
1/4"	3/8"	3/8"	FASTENER DIAMETER																		
1.75"	2.5"	2.68"	EMBEDMENT LENGTH																		
2.5"	3"	4"	EDGE DISTANCE																		
508#	764#	340#	FASTENER LOAD CAPACITY																		

Supporting structural elements shall be designed by a registered professional engineer for wind loads in addition to other loads. This drawing does not address the wall design, but only door attachment. Wall construction is shown only for illustration purposes. The building designer is responsible for ensuring that the wall is sufficient to carry the door live and static loads. This drawing does not address the spring pad connections. Registered professional engineer may approved an alternative design.

John E. Scates, P.E.  
 3121 Fairgate Drive  
 Carrollton, Texas 75007  
 Florida P.E. # 51737  
 TXPE 56308, F-2203

	SCALE	none
	DATE	2-18-2015
Concrete Wall Attachment Detail		
C.H.I. Drawing: BJA-105		Rev.-06

Place as many track brackets as necessary at an on-center (O.C.) spacing no greater than the distance shown on chart for appropriate pressure and width combination.  
 Refer to door drawing installation instructions for floor to first bracket spacing.  
 Field drilling of bracket attachment holes into the track will be required.  
 Lag screw: 5/16" diameter x 1-5/8" minimum long;  
 must conform to ANSI/ASME B18.2.1  
 Lag screws must be seated in full height frame members.  
 1-1/2" minimum lag screw embedment into structural wood.  
 1/2" minimum lag screw edge distance required.



**MAX TRACK BRACKET SPACING (Inches) FOR DOOR WIDTH vs DESIGN PRESSURE FOR SPRUCE-PINE-FIR**

WIDTH IN FEET	DESIGN PRESSURE IN POUNDS PER SQUARE FEET													
	12 PSF	15 PSF	18 PSF	21 PSF	24 PSF	27 PSF	30 PSF	33 PSF	36 PSF	39 PSF	42 PSF	46 PSF	50 PSF	53 PSF
≤ 7'	28"	28"	28"	28"	28"	28"	28"	28"	28"	25"	24"	21"	20"	19"
8'	28"	28"	28"	28"	28"	28"	28"	26"	24"	22"	21"	19"	17"	16"
9'	28"	28"	28"	28"	28"	28"	26"	23"	21"	20"	18"	17"	15"	14"
10'	28"	28"	28"	28"	28"	26"	23"	21"	19"	18"	16"	15"	14"	13"
12'	28"	28"	28"	28"	24"	21"	19"	17"	16"	15"	14"	12"	11"	11"
14'	28"	28"	28"	24"	21"	18"	16"	15"	14"	12"	12"	10"	10"	9"
15'	28"	28"	26"	22"	19"	17"	15"	14"	13"	12"	11"	10"	9"	8"
16'	28"	28"	24"	21"	18"	16"	14"	13"	12"	11"	10"	9"	8"	8"
18'	28"	26"	21"	18"	16"	14"	13"	11"	10"	10"	9"	8"	7"	7"
20'	28"	23"	19"	16"	14"	13"	11"	10"	9"	9"	8"	7"	7"	6"

For door jambs Spruce Pine Fir (SPF), specific gravity = 0.42 or better;  
 max load per anchor = 67% of 439 pounds.  
 Maximum load per jamb = 0.5 x (door height) x (door width) x (maximum positive pressure)  
 Alternative design may be approved by a licensed professional engineer.  
 Supporting structural elements shall be designed by a licensed professional engineer  
 for wind loads in addition to other loads.  
 The suitability of the structural building components must be verified by the engineer of  
 record for the building.

Professional Engineer's seal provided only for  
 verification of windload construction details.

John E. Scates, P.E.  
 3121 Fairgate Drive  
 Carrollton, Texas 75007  
 Florida P.E. # 51737  
 TXPE 56308, F-2203

	SCALE	none
	DATE	4-20-2017
<b>Track Bracket Attachment Detail          Spruce Pine Fir (SPF) Jambs</b>		
C.H.I. Drawing: BJA-106		Rev.-04